






Scan here for access to solution website page for other documents

Stravilink IJH-S Datasheet

Stravilink IJH-S is an Isolation Joist Hanger with Springs, designed to support suspended ceiling systems of joist structural floors, optimizing sound insulation between vertically stacked rooms.



- Side-mounted zinc-plated steel angle, gusseted for enhanced resistance to bending
- Ideal for lateral fixation
- Equipped with steel springs featuring a natural frequency of approximately 4 Hz at design load
- Available in different spring options, supporting loads from 5 to 78 kg
- Colour-coded springs are available for different load ranges, making it easy to verify on-site that the correct hanger is used
- Includes a steel washer with integrated thread, compatible with standard drop rod ceiling systems
- Interfaces seamlessly with all ceiling types
- Accommodates variable void depths
- Easy positioning
- Simple and fast installation process





PACKAGING

Model	Reference Quantity per Box Weight per Box [kg]		Dimension of Box [cm]	
Stravilink IJH-S80	002026	42	10	28 x 18 x 17
Stravilink IJH-S250	002028	42	10	28 x 18 x 17
Stravilink IJH-S500	002030	42	10	28 x 18 x 17

Model	Design Load		Resonance Frequency at Design Load	Load Range (per Hanger)		Pad Colour
	kg	Ν	Hz	kg	Ν	
Stravilink IJH-S80	8	80	4	5-11.5	50-115	Signal Yellow 😑
Stravilink IJH-S250	25	250	4	10-39	100-390	Traffic Red 🔴
Stravilink IJH-S500	50	500	4	25-78	250-780	Signal Blue 🔵


Notes: Admissible load of steel elements: 1274 N. Products are suited up to a C2 environment (atmosphere with little or no degree of pollution). The temperature range of use is between -30°C and 70°C. To assess which type is appropriate the following information is needed: 1) The weight and construction of the supported ceiling - this will determine the type of hanger; 2) The weights and support locations of any items hung from the ceiling.





Notes: All dimensions in milimeters (mm). *Available in M8 upon request.







The resonance frequency of a Stravilink hanger can be determined by its load. To start the calculation use the graph "Deflection as Function of Load" this will provide the deflection at the specified load. Then moving horizontally to the right hand side plot "Deflection as Function of Frequency" on which the corresponding resonance frequency can be found. As an example, the resonance frequency of a Stravilink IJH-S250 loaded with 300 N is determined. The corresponding deflection is 19 mm. The resonance frequency of a spring at 19 mm deflection is 3.6 Hz.

ACCESSORIES




Perimeter Strip

1. Self-adhesive perimeter strip 10 mm thick to isolate the ceiling from the adjacent walls.

Note: Standard widths of 50 mm, 100 mm, and 150 mm are available in 10 lm rolls.










MF grid



- 5. Plasterboards, gypsum board or dry lining
- 6. British gypsum MF7 primary channel
- 11. British gypsum fea1 angle
- 12. Absorption layer

DISCLAIMER

This information is accurate to the best of our knowledge at the time of issue. Information, data and recommendations provided are based on industry accepted testing and prior product usage. It is intended as descriptive of the general capabilities and performance of our products and does not endorse applicability for any particular project. We reserve the right to change products, performance, and data without notice. This document replaces all information supplied prior to the publication hereof.